



## **Fill-N-Build (FNB) Exterior Ceramic Spackle & Mastic Application Guidelines**



Unlike typical drywall mud **FNB** is designed for exterior treatment of corner beads.



Apply a base coat of **AcraCream** over a clean corner bead to seal & waterproof.



Apply Carrara **Finish Tape** into the wet AcraCream.



Pull the mud knife down the Finish Tape making sure the tape is flat and fully adhered.



Allow the AcraCream & Finish Tape to fully dry before applying the **FNB**



**FNB** spreads easily, smoothes irregular surfaces and can be feathered to a 0 edge.



**FNB** is ideal to smooth & level wherever corner beads are used, including: columns, arches and other building details (but not for panel joints & seams). Once dry and cured, FNB is ready for ColorFlex or ColorTex-AE base coat and Carrara Stucco finish coat.